

POST BASE KIT INSTALLATION INSTRUCTIONS

Footing installation:

- Drill a 3/4" hole 10" deep min. into the center of the viga or post. Clean out dust. Half fill the hole with SET epoxy. Insert the all-thread rod and allow epoxy to set. Slip post base over the rod and secure to the post.
- Drill a 3/4" hole 5" deep min. into the center of the footing. Clean out the dust. Half fill the hole with SET epoxy. Insert the all-thread rod into the hole.

4" minimum slab installation:

- Drill hole into viga post as noted above. Align post surface with edge of slab. Mark center of post on slab. Drill a 3/4" hole 3-1/2" deep into slab. Half fill the hole with SET epoxy. Insert the all-thread rod into hole.
- Not recommended for non-top-supported installation such as fences.

